



- Initial setup



When keeping the prism for multiple readings, keep it with the distance of 4 cm from the previous one. This is to optimize the space of the paper

θ	i_1	i_2	d
60°	30°	76°	48°
50°	40°	58°	40°
45°	45°	52°	37°
40°	50°	49°	40°
30°	60°	40°	41°
20°	70°	35°	45°



$$\begin{aligned}
 r_1 + r_2 &= A \text{ --- ①} \\
 i_1 + i_2 &= d + A \text{ --- ②} \\
 \text{At minimum deviation} \\
 i &= i_1 = i_2, \quad r_1 = r_2 = r \\
 \text{①} \Rightarrow r + r &= A \quad \text{②} \Rightarrow 2i = d + A \\
 2r &= A \quad i = \frac{d + A}{2} \\
 r &= A/2
 \end{aligned}$$

Important point

- Why should we use an equilateral prism for this experiment?


Otherwise, we won't be able to see the refraction as above

- Why can we get 2 pairs of readings by just measuring the i_1 and i_2 for one angle?

Because we can take the initial i_1 as the i_2 for a second pair by interchanging the direction of light entering the prism. This is due to the principle of reversibility of light.

- Why should we keep the pins P1 and P2 with maximum distance apart?

To reduce the error when drawing the lines



- When comparing 2 prisms, if the prism angle changes, what are the factors that will change with it?

Minimum deviation will change - if A is higher, the D will be higher, when A is lower, D will be relatively lower

The way the graph of d and i is drawn changes. I.e when $A = 60$ the graph will start from $i = 30$ (because any incident angle before 30 degrees will result in total internal reflection) but if the $A = 30$, the graph for i will start from 0 as no total internal reflection will happen.

A – Prism Angle

D – Deviation

$$A \propto D$$

refractive index to be 1.5.

