


- Concept

When 2 substances of 2 different temperatures are mixed together, the temperature gained by the cold substance is equal to the temperature lost by the warm substance

- Initial setup



- Measurements you need to take in the correct order.

1. Measure the mass of the calorimeter with the stirrer. $M_1 - (M_c)$
2. Fill the calorimeter with water and then measure the mass. $M_2 - (M_c + M_w)$
3. Measure the initial temperature of water. θ_1
4. After heating the lead shots (in the steam bath), get the temperature θ_2 (This can be taken as 100°C if needed)
5. After adding the heated lead shots to the calorimeter, get its maximum temperature θ_3

6. Final mass of the calorimeter with its contents M_3

After taking these readings, we can find the specific heat capacity of the lead shots using the equation $H = mS\theta$

$$M_m = \text{Mass of the metal balls (lead shots)}(M_3 - M_1)$$

$$M_w = \text{Mass of the water}(M_2 - M_1)$$

$$M_c = \text{Mass of the calorimeter + Stirrer}(M_1)$$

$$S_m = \text{Specific heat capacity of metal balls}$$

$$S_w = \text{Specific heat capacity of water}(4200)$$

$$S_c = \text{Specific heat capacity of calorimeter}(4000)$$

$$H = mS\delta\theta$$

$$M_m S_m \delta\theta = (M_C S_c + M_w S_w) \delta\theta$$

$$M_m S_m (\theta_2 - \theta_3) = (M_C S_c + M_w S_w) (\theta_3 - \theta_1)$$

$$\therefore S_m = \frac{(M_C S_c + M_w S_w) (\theta_3 - \theta_1)}{M_m (\theta_2 - \theta_3)}$$

Important points


- Why do we use a boiling tube to heat the lead shots instead of using a water bath to heat them?

If we use a water bath, once the lead shots are heated and we want to put them in to the calorimeter, the lead shots would be wet and have water around them. And since we can't change the amount of water (which would lead to an error in the calculation), we need to use the boiling tube to heat it.

- Why can't we heat the lead shots directly?


Because it's hard to maintain a uniform temperature both inside and outside the lead shots if we heat them directly. Since we only measure the outside temperature of the shots, you will not be able to make sure that the inside of the shots are at the same temperature as the outside.

er and a stirrer



So to maintain a uniform temperature of the shots, we need an instrument as below and heat the shots.

With this, when we heat the water, at 100°C its gonna stay the same till all the water is vaporised (due to latent heat). So we can make sure the temperature is uniform for a while till both inside and the outside of the lead shots are at thermal equilibrium.



- Why do the lead shots have to be completely submerged in the water inside the calorimeter?

Because if not, the heat from the lead shots would be released to the environment

- Why do we use the method of cooling correction to do this experiment?

When we do this experiment, there is always gonna be a heat loss to the environment no matter what. So to reduce this we use the cooling correction method.

Cooling correction: Let's assume that the room temperature is 30°C. Instead of starting the experiment at the room temperature, we cool the system to 25°C and start it. So once the lead shots are put to the calorimeter, as the system is cooler than the environment, heat will be gained to the system. Then after it goes above 30°C, since the system is hotter than the environment, heat will be lost from the system.

Therefore we can make an assumption that the heat gain at the first part and the heat lost at the last part of this process are equal and hence there was no net loss of heat to the system.

- When taking the temperature of the water in the calorimeter after putting the lead shots (θ_3), what temperature should be taken?

When you start putting the heated lead shots the temperature will rise. After putting all the shots there will be a temperature you see in the thermometer, don't take that. Keep stirring and that temperature will increase by a little (Because stirring will uniformly distribute the temperature). Then after sometime the temperature will go down (as it's losing heat to the environment).

The temperature we should take is the maximum temperature that was seen within the calorimeter.

- Why can't we use either a huge block of lead or small lead pieces for this experiment?

A huge lead block can't be used as there is a considerable difference between the surface temperature and the internal temperature of the block. Also the big block will take a longer time to come to a heat equilibrium with water as the surface area is less - hence taking longer time for the experiment (hence more heat loss).

Small lead dust can't be used as these particles may occupy the inner surface of the calorimeter above the water level when stirring.

- What is the ideal level of water that needs to be added to the calorimeter?

Water should be filled up to 2/3 of the calorimeter.

It can't be filled completely as it can spill out when the lead shots are added. And there can't be too less water as the water level should cover the lead shots completely.

- Why is using steam better to heat the lead shots in the experiment?

Because the temperature of boiling water is hard to keep constant since it doesn't contain latent heat. But steam does contain latent heat and has the temperature of 100 Celsius which doesn't change.

- How do we prevent the heat loss to the environment from the calorimeter?

To prevent,

Conduction - Insulate/lag the calorimeter with a regiform or an insulating material

Convection - Close the calorimeter with a lid

Radiation - Make the calorimeter's surface shiny

- Why do we heat the lead shots up to 100°C?

To maintain the uniform temperature in both inside and outside of the lead shots for a while without changing (as boiling point doesn't change).